

Take two – Uncertainties with EC_x calculations are reduced by assessing confidence limits as well as performing the “good old” visual inspection of data

Thomas Schmidt, Magdaléna Cornement, Bettina Hodapp, Stefan Höger
IES Ltd, Benkenstrasse 260, 4108 Witterswil, Switzerland

SETAC Europe 30th Annual Meeting
Dublin Ireland, May 03-07, 2020
Final ID: 4.06P.9

Introduction

The use of EC_x (Effect Concentration with an effect of x %) instead of the No-Observed Effect Concentration/Lowest Effect Concentration (NOEC/LOEC)-approach is the preferred endpoint in many OECD guidelines (e.g. OECD 201 (2011)). For the assessment of the quality of the calculated EC_x and the reliability of the used models many parameters are suitable:



- **Chi²-value** for the correspondence between the distribution of the calculated values and the experimental data.
- **F-value** from the F-test for the statistical significant difference of the slope of concentration/dose-effect curve from zero,
- **Coefficient of determination r²** for the goodness of fit of the concentration/dose-effect curve.
- **Normalized width (NW) of confidence limits of an EC_x** (i.e. difference between upper/lower 95 % CI, divided by EC_x (EFSA (2019)).
- **Overlap of EC₁₀ and the lower 95 % confidence interval of EC₂₀** (EFSA (2019)).

Problem

All these parameters can demonstrate a strong reliability of the one selected concentration-effect curve but a careful visual inspection of this curve is sometimes essential to identify the unsatisfactory fit for the whole range of concentrations. This can be observed when:

- 1) the effect increases slowly at the lower test concentrations and increases rapidly at the highest test concentrations (**Figure 1 & 2**).
- 2) the effect does not follow a continuous concentration-effect relationship but shows a saturation in one range of concentrations and increases afterwards again (Figure 3 & 4).

Therefore, the use of only one concentration-effect in the risk assessment might over-/underestimate the EC₁₀, EC₂₀ and EC₅₀.



Conclusion

Based on the assumption that one concentration/dose-effect curve does not reliably represent the observed pattern of effects over the whole range of tested concentrations/doses, two different concentration/dose-effect calculations in two different concentration/dose ranges can improve the estimation of reliable EC/D₁₀ and EC/D₂₀ as well as EC/D₅₀ with an acceptable representation of the experimental data for the whole data set.

Acknowledgements

Thanks to Monika Ratte from ToxRat® Solutions for the discussions.

Sources

1. EFSA (2019): Outcome of the Pesticides Peer Review Meeting on general recurring issues in ecotoxicology. DOI:10.2903/sp.efsa.2019.EN-1673. 28 June 2019. 117 pages.
2. OECD 213 (1998): OECD Guidelines for Testing of Chemicals, Section 2, No. 213: Honeybees, Acute Oral Toxicity Test. ISBN: 9789264070165 (PDF). DOI: 10.1787/9789264070165-en. Adopted 21 March 1998. 8 pages.
3. OECD 201 (2011): OECD Guidelines for Testing of Chemicals, Section 2, No. 201. Freshwater Alga and Cyanobacteria; Growth Inhibition Test. ISSN: 20745761 (online). ISBN: 9789264069923 (PDF). DOI: 10.1787/9789264069923-en. Adopted: 23 March 2006, Annex 5 corrected: 28 July 2011. 25 pages.
4. ToxRat Professional (Version 3.3.0), ToxRat® Solutions GmbH.